



OUTER MIRROR SWITCH

INSPECTION

1. INSPECT OUTER MIRROR SWITCH ASSEMBLY

(a) The L position of the left/right adjustment switch:
Measure the resistance of the mirror switch.
Standard resistance (for left side)

MI

Tester Connection	Switch Condition	Specified Condition
4 (VL) - 8 (B) 6 (M+) - 7 (E)	UP	Below 1 Ω
	OFF	10 k Ω or higher
4 (VL) - 7 (E) 6 (M+) - 8 (B)	DOWN	Below 1 Ω
	OFF	10 k Ω or higher
5 (HL) - 8 (B) 6 (M+) - 7 (E)	LEFT	Below 1 Ω
	OFF	10 k Ω or higher
5 (HL) - 7 (E) 6 (M+) - 8 (B)	RIGHT	Below 1 Ω
	OFF	10 k Ω or higher

If the result is not as specified, replace the switch assembly.

(b) The R position of the left/right adjustment switch:
Measure the resistance of the mirror switch.

Standard resistance (for right side)

Tester Connection	Switch Condition	Specified Condition
3 (VR) - 8 (B) 6 (M+) - 7 (E)	UP	Below 1 Ω
	OFF	10 k Ω or higher
3 (VR) - 7 (E) 6 (M+) - 8 (B)	DOWN	Below 1 Ω
	OFF	10 k Ω or higher
2 (HR) - 8 (B) 6 (M+) - 7 (E)	LEFT	Below 1 Ω
	OFF	10 k Ω or higher
2 (HR) - 7 (E) 6 (M+) - 8 (B)	RIGHT	Below 1 Ω
	OFF	10 k Ω or higher

If the result is not as specified, replace the switch assembly.